


INSTALLATION DIAGRAM:



A "Drip Loop" should be arranged for EACH cord connecting the controller. The "Drip Loop" prevents water from traveling along the cord and coming in contact with the Sensor connections or the electrical receptacle.